



Pos 36 marker for pufferhøjde monteres efter typ. 79383.
 Pos 21, Pufferhøjdeschilder nach Zeichn. 79383 (WAG C118/01 & 6) aufsetzen.

Placering af "DSB" på Mr. MR vognside
 Aufsetzen der "DSB" auf der MR Wagnseite.

Typ. ændr.	28.11.97	02
Typ. ændr.	11.11.97	03
Pos 21, 22 og 69 ændr.	23.11.97	04
Pos 23, 26, 28, 29, 30 og 33 flyttet	17.12.97	05
Åbning af pos 1 ændret	18.1.98	06

Målestok: Teg. 1:25
 1:25

Udg. af 10103101/02/03/04

77539

Gruppe: 0