


Slejlstangspander.


Loko. 1-9, 11-15.

Model L. 74.
(2 set)




Knobbelstangspander.

Model L. 14.




Model L. 29.




Excenterstangspander.

Frydshovedpander & Sko.

Model L. 79.




Model L. 38.




Længde 300.

Loko. 10, 26-31.


Model L. 25.




Model L. 124.




Model L. 97.




Model L.



Model L. 121.




Model L. 104.




Loko. 16, 19, 20.

Model L. 90.




Loko. 19-20.




Model L. 167.

Model L. 34.




Model L. 35.



Loko. 16.


Model L. 173.



Loko. 19-20: Som Loko. 10, 26-31.


Loko. 16.

Model L. 119.



Loko. 19-20.

Model L. 81.




Loko. 16.


Model L. 122.

Loko. 21-24.


Model L. 99.




Model L. 168.




Model L. 28.




Model L.



Model L. 9.




Model L.




Loko. 17-18.

Model L. 171.




Model L.

Model L.




Model L. 172.




Loko. 25.

Model L. 170.




Model L.

Model L. 169.




Model L.




Som Loko. 16.


Model L.



Model L. 174.



Model L.



Loko 21